



## P-8 Super Hauler Bag Instructions

### Bag Contents:

- |                      |                                    |                   |
|----------------------|------------------------------------|-------------------|
| 1 – Hauler Bag       | 2 – Shelf Panels with Divider      | 1 – Large Drawer  |
| 1 – Tool Caddy       | 6 – Medium Drawer End Caps (9 ½ ") | 3 – Medium Drawer |
| 1 – Left Side Panel  | 2 – Large Drawer End Caps (19 ½ ") | 1 - Small Drawer  |
| 1 – Right Side Panel | 2 – Small Drawer End Caps (8")     |                   |

**Note:** All drawer surfaces come with double-sided tape pre-applied, however for best results ProTek R/C recommends the use of contact cement or hot glue to ensure proper adhesion of drawers.

### Step 1: Assembly of Hauler Bag

**1A)** Remove bag from plastic, lay on flat surface with the front of the bag facing upwards. Place left side panel (without notches) in bag with the top of the panel underneath small plastic holder at top of bag. Slide lower portion of side panel into position. Repeat for right side.

Note: Velcro gap on left side panel should be larger on top than on the bottom.



**1B)** Starting with the bottom shelf, secure the Velcro strip for shelf to left and right side of hauler bag. Make sure to push the shelves as far back as possible and attach to the Velcro strip to the rear of the bag. Fold down divider. Repeat for top shelf.



**1C)** Completed hauler bag with shelves.



## Step 2: Assembly of Tool Caddy

2A) Place tool caddy on flat surface and pre-bend all hinged surfaces.



2B) Fold both sides up towards the center.



2C) Fold end up and over flaps from the sides. Push tab into the slot on bottom of the tool caddy. Repeat for opposite side.



2D) Completed tool caddy.



2E) Secure velcro for pre-installed tool holder and place tool caddy in top of hauler bag.



### Step 3: Assembly of Storage Drawers

3A) Remove Medium Drawer and place on flat surface. Pre-bend all hinge surfaces for easier assembly.



3B) Remove covering from double-sided tape, fold side panel up, and tuck small flap inside end panel. Secure to end panel with double-sided tape.



3C) Repeat with opposite side.



3D) Once both sides have been completed, remove covering from double-sided tape on the back panel, and place the end cap over the top to ensure to cover the flaps from the side panel and end panel. Repeat for the front of the drawer.



3E) Repeat for all drawers.



## Step 4: Final Assembly

4A) Place all drawers in hauler bag.



Front



Back

